

Use this button to turn both the cable box and TV on and off.

It's possible to get the TV and cable box out of sync. Use the "TV" or "CBL" button then the "Power" button to control individually.

Channel listing

